






Installation Manual



MODEL: ESR-8190/ESR-8180
ESR7190B/ESR-7180B


SIZE: 800*1000*2000MM
800*1200*2000MM

No	Element	Quantity
(H)		1x
(I)		8x
(J)	 ST4*30	8x
(K)	 ST4*10	6x
(L)		2x
(M)		1x
(N)	 M8x20	4x
(O)	 M8x25	4x
(P)		8x
(Q)		6x
(R)	 φ 2.8	1x
(S)		2x
(U)		1x







1




2






1




2



3

3



4

